

SUPERBLOCK LINE



100% Made in Italy



45°C 113°F

Sbalzo termico
Thermal shock



+70°C +158°F

Idoneo al microonde
Microwave-safe



-20°C -4°F

Idoneo al freezer
Freezer-proof



Privo di BPA
BPA-free



Idoneo per lavastoviglie
Dishwasher safe



Lavaggio a mano
Hand wash

Articolo in vetro sodico
calcico

Articole made of soda lime
glass



✓

✓

✓

✓

✓

Senza coperchio
Without lid

Coperchio Polipropilene
Moplen RP2380

Lid Polypropylene
Moplen RP2380



✓

✓

✓

✓

Guarnizione in gomma
termoplastica blu

Thermoplastic rubber
gasket blue

✓

⊘

✓



100% Made in Italy



45°C 113°F

Sbalzo termico
Thermal shock



+70°C +158°F

Idoneo al microonde
Microwave-safe



-20°C -4°F

Idoneo al freezer
Freezer-proof



Privo di BPA
BPA-free



Idoneo per lavastoviglie
Dishwasher safe



Lavaggio a mano
Hand wash

Articolo in vetro sodico
calcico

Articole made of soda lime
glass



✓

✓

✓

✓

✓

Coperchio Polipropilene
Moplen RP2380

Lid Polypropylene
Moplen RP2380



✓

✓

✓

✓

✓

Guarnizione blu in gomma
termoplastica TPE-S

Thermoplastic rubber gasket
blue TPE-S

✓

✓

⊘

✓

Guarnizione valvola in gomma
termoplastica colore naturale

Valve thermoplastic rubber
gasket in natural colour

✓

✓

✓

✓

Valvola blu Polipropilene
Moplen RP2380

Blue Valve Polypropylene
Moplen RP2380

✓

✓

✓

✓

✓



EN – GENERAL WARNINGS

- Use the container with caution as the glass breakage may cause injury
- Wash the food storage container before first use
- Fill the container up to half inch below the rim and place the lid on
- Following the heating, always handle the container with oven mitts
- Place the container on a flat surface. To avoid burns keep the container away from your face and use suitable hand protectors. Handle the lid carefully to

slowly release the hot steam and place the lid on a flat surface

- Place your frozen or heated container on a dish towel. Beware of the direct contact with cold and/or wet surfaces that may cause breakages
- Always remove the lid only after a few minutes from taking it out of the freezer
- Do not use abrasive brushes and sponges to better keep the glass and the lid longer
- The takeout and hand washing of the perimeter gasket is recommended
- To avoid glass damage the use of wooden tools or not sharp-edged utensils is recommended
- Set the microwave on defrosting/heating programs only with a power suitable for the allowed limit temperature
- Neither use the container in the oven, nor on the open flame or on the electric stove directly

WARNINGS SUPERBLOCK AUTOMATIC VALVE

- The valve opens automatically when used in the microwave and does not interfere with the food preservation



EN – GENERAL WARNINGS

- Use the container with caution as the glass breakage may cause injury
- Wash the food storage container before first use
- Fill the container up to half inch below the rim and place the lid on
- Following the heating, always handle the container with oven mitts
- Place the container on a flat surface. To avoid burns keep the container away from your face and use suitable hand protectors. Handle the lid carefully to

slowly release the hot steam and place the lid on a flat surface

- Place your frozen or heated container on a dish towel. Beware of the direct contact with cold and/or wet surfaces that may cause breakages
- Always remove the lid only after a few minutes from taking it out of the freezer
- Do not use abrasive brushes and sponges to better keep the glass and the lid longer
- The takeout and hand washing of the perimeter gasket is recommended
- To avoid glass damage the use of wooden tools or not sharp-edged utensils is recommended
- Set the microwave on defrosting/heating programs only with a power suitable for the allowed limit temperature
- Neither use the container in the oven, nor on the open flame or on the electric stove directly

WARNINGS SUPERBLOCK

- Remove the lid before use in the microwave. The lid can be rested on the top of the container, during the re-heating in order to avoid spatters, but do not seal.